



OceanTRx7TM

Maritime Stabilized VSAT System



Technical Note Shunt Regulator

Document: TEC32-1664-007, Revision A September 2013



Copyright

© 2013 Orbit Communication Systems Ltd. All rights reserved.

All product names are trademarks of Orbit Communication Systems Ltd.

Other names are the property of the respective owners.

No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, electronic or otherwise, without the prior written permission of Orbit Communication Systems Ltd.

Disclaimer of Warranty

Orbit Communication Systems Ltd. has made every effort to ensure the accuracy and relevancy of the material in this document. It is expected that all sections of this document will be read thoroughly and that all information and procedures should be fully understood.

However, Orbit Communication Systems Ltd. assumes no responsibility for any errors that may appear in this document, and reserves the right to make changes to the document without notice.

Orbit Communication Systems Ltd. makes no warranty of any kind in regard to this document, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose.

Orbit Communication Systems Ltd. disclaims any responsibility for incidental or consequential damages in connection with the furnishing, performance or use of this document.

Parts of this document may be based on hardware or software developed by third-party vendors. Orbit Communication Systems Ltd. disclaims any responsibility for the accuracy of this document with respect to such hardware and software, and assumes no responsibility for incidental or consequential damages arising due to discrepancies between this document and such hardware or software.



Revision History and Control

Revision History

Rev#	Modified by	Date	Comments
	Albert	September 24, 2013	New Release



About this Manual

This manual is designed to guide you through the procedures required for maintaining the SHUNT REGULATOR for the OceanTRx7™ Maritime Satellite Communication System.

Text Conventions

Style	Indicates	Example
Text	Normal descriptive text	Contents
Text	Words or figures that appear on the screen or that should be typed The name of a file or directory	System Status
<text></text>	A key to be pressed	<esc></esc>
TEXT	The name of a hardware component	ANTENNA
Text	The name of a GUI element	Operation Screen
>	The description of a procedure	> To configure

Notations



Indicates important information that should be noted.



Indicates a potential hazard.



Indicates the safest method of installation or an operation that *must be adhered to*.



Effective Releases

This document is effective for both OrBand™ and OceanTRx7™ Maritime Satellite Communication Systems.

For a description of the changes between OrBand[™] and OceanTRx7[™], refer to the OceanTRx7[™] Maritime Satellite Communication System Release Notes.



Table of Contents

1	Int	roduction	1
	1.1	Purpose	1
	1.2	Shunt Regulator Description	1
	1.3	Spare Kit Contents	2
	1.4	Required Tools and Parts	2
2	Pre	eliminary Procedures	3
3	Re	placing the Shunt Regulator	4
	3.1	Removing the Shunt Regulator (OceanTRx7™/OrBand™)	4
	3.2	Installing a Shunt Regulator	6
4	Pe	rforming Verification Test	7
5	Ар	pendixes	8
	5.1	Appendix A: Replacing Shunt Regulator cable (OrBand™ with OceanTRx7™)	8
	5.1	I.1 Removing Shunt Regulator cable (OrBand™)	8
	5.1	I.2 Installing Shunt Regulator cable (OceanTRx7™).	.11



1 Introduction

1.1 Purpose

The purpose of this Technical Note is to provide detailed instructions on how to replace and configure a SHUNT REGULATOR.

1.2 Shunt Regulator Description

The SHUNT REGULATOR is a DC voltage stabilizer that absorbs the excess back-EMF energy reflected from the SERVO MOTORS whenever the system is rapidly decelerated. The unit, which consists of a power resistor and switching circuit, protects the SERVO DRIVER'S 96 VDC power supply from overvoltage due to electrical feedback.

The OceanTRx7™ SYSTEM SUPPORTS the following shunt regulator:



Figure 1-1: Shunt Regulator – OceanTRx7™

The SHUNT REGULATORs have the same mechanical interface and different electrical interfaces.



When replacing old SHUNT REGULATOR (ORBANDTM) with new SHUNT REGULATOR (OCEANTRX7TM) old electrical cable interface must be removed and replaced with new one.



1.3 Spare Kit Contents

The following table provides a list of the parts in the SHUNT REGULATOR spare kit.

Table 1-1: Spare Part Kit Contents

KIT32-1664-003-SP				
P/N	Description	Quantity		
31-0301-9-2	CABLE FOR NEW SHUNT REGULATOR AL-7107	1		
L00128003	SHUNT VOLTAGE REGULATOR	1		

1.4 Required Tools and Parts

The following table provides a list of tools and customer-supplied parts that are needed to perform the procedures in this Technical Note.

Table 1-2: Required Tools and Parts

Tool/Part Name	Notes	Figure
Phillips screwdriver		
Tie cutter		
Allen keys: 3mm		and the second



2 Preliminary Procedures

> To Perform Preliminary Procedures:

The preliminary procedure described below must be performed before replacing the SHUNT REGULATOR:

- 1. Open the RADOME hatch.
- 2. Switch off the ADE POWER BOX at the ANTENNA PEDESTAL base (located inside the RADOME).
- 3. Toggle the SERVO DRIVER MAINT/OPER switch on the servo driver to MAINT position to release the brake and allows smooth movement of the axis .
- 4. Manually rotate the PEDESTAL AXES to gain convenient access to the serviced unit.



In the following procedures, be very careful when tightening and loosening the screws with which the parts are assembled and attached to the system. Some of these screws are delicate and can be damaged by excess force. When using an Allen key make sure to insert the key all the way into the screw head to avoid thread stripping.





WARNING!

The Utility Outlet is connected directly to the vessel's AC voltage input terminals (125 VAC / 250 VAC). Therefore, there still exists live voltage at the Utility Outlet after disconnecting the power supply to the ADE using the Mains Power On/Off Switch.

Only qualified and authorized personnel are allowed to carry out system service/maintenance procedures.



3 Replacing the Shunt Regulator

3.1 Removing the Shunt Regulator (OceanTRx7™/OrBand™)

> To Remove the Shunt Regulator:

Step 1

Locate SHUNT VOLTAGE REGULATOR.



When replacing a SHUNT REGULATOR (ORBAND™) with a SHUNT REGULATOR (OCEANTRX7™) refer to Appendix A for a cable replacement description.




Step 2

Unlock SHUNT VOLTAGE
REGULATORS plug and pull
plug down to remove.



Gently unlock plug before pulling down.






Use a Philips Screw driver to release two captive Philips screws securing the SHUNT VOLTAGE REGULATOR to the PEDESTAL.



Hold SHUNT VOLTAGE
REGULATOR with other hand
while unscrewing Philips
screws.



OrBand™ system SHUNT system t use Allen screws.






3.2 Installing a Shunt Regulator

> To Install a Shunt Regulator:

Step 1

Secure the new SHUNT
VOLTAGE REGULATOR to the
PEDESTAL using its two
captive Philips screws.



Step 2

Connect SHUNT VOLTAGE

REGULATOR'S plug. •

Attention: Make sure plug

locked.





4 Performing Verification Test

> To Perform Verification Test:

After the SUNT REGURALTOR has been replaced, perform the following test procedures to verify system functioning

- 1. Start up the system (see the *OceanTRx7™ Installation and Operation Manual*).
- 2. To make sure the technical process completed successfully click on Test Traj.
- 3. Make sure no error messages appear in the System Messages window. F9 Shutdown AGC (dBm) Date StepTrack Locked Mode Acquire Sat Preset -62 SatVld Step-Track IRD Unlock 5.0 PolSw Pnt-to-Sat -68 SatPreset 351.344 351.200 TogglePol Stand-by NSS9 183 °E 177° W Satellite Manual Test Traj Elev PolSkew -44.942 -79.00 14.104 Elev. 13.518 -45.000 PolSkew



5 Appendixes

5.1 Appendix A: Replacing Shunt Regulator cable (OrBand™ with OceanTRx7™)

5.1.1 Removing Shunt Regulator cable (OrBand™).


Step 1

Disconnect the wire connector from the SHUNT VOLTAGE REGULATOR.



Step 2

Locate the POWER SUPPLIES module.



Step 3

Cut tie wrap securing GPS MODULE.





Remove GPS MODULE.

Attention: Scotch securing
GPS MODULE to its place.



Step 5

Remove the screws securing the POWER SUPPLY cover to the PEDESTAL using a Phillips screwdriver.

Four screws at the lower part of the cover.

Four screws at the upper part of the cover.







Remove the POWER

SUPPLIES cover.




Step 7

Cut tie wrap securing SHUNT REGULATOR'S (ORBAND™) cable.



Step 8

Use a screwdriver to
disconnect the SHUNT
REGULATOR'S (ORBAND™)
wires connected to the
POWER SUPPLY unit and
remove the cable.





5.1.2 Installing Shunt Regulator cable (OceanTRx7™).

Step 1

Insert the new SHUNT
REGULATOR'S
(OCEANTRX7TM) wires to
their proper marked position
on the POWER SUPPLY unit
and tighten them using a
screwdriver.




Make sure you fasten each wire to the proper position. Note the markings and colors!

Step 2

Use tie wraps to secure SHUNT REGULATOR'S (OCEANTRX7TM) cable.

Step 3

Reinstall the POWER SUPPLY cover.







Hand tight the four upper—Philips screws of the POWER SUPPLY's cover.

Hand tight the four lower

Philips screws of the POWER

SUPPLY's cover.



Use a Phillips screwdriver to fasten all eight screws securing the POWER SUPPLY's cover. to the PEDESTAL.

Step 5

Reinstall the GPS MODULE.



Scotch securing GPS MODULE to its place.

Step 6

Use a tie wrap to secure the GPS MODULE.

